


Nomographs

**for Determination of Adjusting Values
of Load Sensing Relay Emergency Valve
475 715 . . . 0**


Nomograph I

to determine the type of pressure spring to be used and spring length L_1



Nomograph II

to determine screw setting length L_2 , the number of separators N to be used and L_3



Description of Nomographs I and II for setting values on Load Sensing Relay Emergency Valve 475 715 . . . 0

Procedure:

1. To determine the type of pressure spring to be used, its setting length L_1 and the required number of separators.

Setting values required:

$$\begin{aligned} p_{\text{on}} (p_1) &= 6.5 \text{ bar} \\ p_{\text{bellows empty}} &= 0.2 \text{ bar} \\ p_{\text{bellows laden}} &= 4.1 \text{ bar} \\ p_{\text{off}} = p_{2 \text{ empty}} &= 1.75 \text{ bar} \end{aligned}$$

- 1.1. The regulating ratio is computed as follows:

$$i = \frac{p_{\text{on}} - 0.8}{p_{\text{off}} - 0.5} = \frac{6.5 - 0.8}{1.75 - 0.5} = 4.56$$

- 1.2. The regulating ratio is entered in Nomographs I and II (Scale Point A). In addition, the pressure difference in the air bellows ($p_{\text{bellows laden}} - p_{\text{bellows empty}}$) – in this case 3.9 bar – is marked (Scale Point B). Connect Points A and B to obtain Point C at the intersection with the spring scale. You can now read the type of spring to be used as well as its length L_1 (unstressed).

- 1.3. Now enter spring length L_1 (Scale Point D) and the spring to be used with spring length L_1 (Scale Point E) in Nomograph II. Enter the bellows pressure for the empty vehicle (Point F) and connect Points A – D and E – F, extending the connecting lines beyond D and E to Subsidiary Lines 1 and 2. This gives you Points G and H.

Connect Points G and H. At the intersection with the subsidiary line you will obtain Point J where you can read off the required number of separators and the length of the screw L_2 .

The values determined by means of the nomographs are approximate values only and may need correction.

2. **Setting of Load Sensing Valve:**

Important:

Before adjusting either screws or pressure p_{41}/p_{42} , there must be no air on port 1/4 since a static feature in the load sensing relay emergency valve 475 715 5. . . 0 would prevent proper adjustment.

Note: Because of the process tolerances and the hysteresis, it is advisable to repeat input from 0 bar after adjustment of the pressure values ($p_{1/4}$ and p_{41}/p_{42}) provided no information is given to the contrary.

- 2.1. After fitting the correct spring using clamp X (set dimension L_1) and the correct number of separators (N) in the load sensing relay emergency valve, screw in screw 2 (L_2) until a definite resistance is felt.

- 2.2. **Setting "empty" adjusting screw**

After pressurizing $p_{1/4}$ with the calculated pressure (in this case 6.5 bar), the load sensing relay emergency valve's "empty" brake pressure (in this case 1.75 ± 0.1 bar) must be delivered at port 2. If the "empty" brake pressure is too high, unscrew adjusting screw W (L_3). If

the "empty" brake pressure is too low, turn it the other way.

Unscrewing adjusting screw W
= to reduce "empty" brake pressure

Screwing in adjusting screw W
= to increase "empty" brake pressure

Important: Do not unscrew adjusting screw W too far (up to max. 23 mm).

- 2.3. **Adjusting "empty" brake pressure.**

After pressurizing ports 41 and 42 with the "empty" bellows pressure + 0.2 bar (in this case 0.4 bar) and port 4/1 with the calculated pressure, the load sensing relay emergency valve must have an output pressure which exceeds the "empty" brake pressure by 0.2 bar with a tolerance of ± 0.1 bar (in this case 1.95 ± 0.1 bar).

If the output pressure is too low, unscrew screw 2. If the pressure is too high, turn it the other way.

Unscrewing screw (2) = to reduce pressure
Screwing in screw (2) = to increase pressure

- 2.4. **Adjusting brake pressure for laden vehicle.**

- 2.4.1 After pressurizing ports 41 and 42 with the bellows pressure for the laden vehicle - 0.1 bar (in this case 4.0 bar), the load sensing relay emergency valve must have an output pressure of input pressure - 0.3 bar with a tolerance of ± 0.2 bar (in this case 6.2 ± 0.2 bar).

If the output pressure is too low:

Determine Δp (difference between actual value and desired value).

Reduce input pressure to 0 bar.

Reduce bellows pressure to 0 bar and then increase it to the value for the unladen vehicle + 0.2 bar (in this case 0.4 bar).

Unscrew screw 2 ($\Delta p = 0.1 \text{ bar} \cong 3 \text{ mm}$).

Unscrew spring clamp until reaching the desired value (in this case 1.95 ± 0.1 bar)

Repeat check 2.4.1.

If the output pressure is too high:

Determine Δp

Reduce input pressure to 0 bar.

Reduce bellows pressure to 0 bar and then increase it to the value for the unladen vehicle + 0.2 bar (in this case 0.4 bar).

Screw in screw 2 ($\Delta p = 0.1 \text{ bar} \cong 3 \text{ mm}$).

Screw in spring clamp until reaching the desired value (in this case 1.95 ± 0.1 bar)

Repeat check 2.4.1.



- 2.5. After setting the values on the load sensing relay emergency valve, repeat all testing operations.

- 2.6. Tighten counter nuts on screws W and 2 (L_2) using the given torque (8 + 2 Nm).

- 2.7. Punch data onto load sensing valve's indicator plate, Part Number 899 144 631 4, and fit plate to the vehicle..

Nomograph I

to determine the type of pressure spring to be used and spring length L_1




$$\text{Regulating ratio } i = \frac{p_{\text{on}} - 0.8}{p_{\text{off}} - 0.5}$$

Pressure difference in bellows


Δp_L in bar

$$\Delta p_L = p_{\text{bellows laden}} - p_{\text{bellows empty}}$$




Wire diam. 4 mm
Pressure spring 896 512 360 4

Wire diam. 3.2 mm
Pressure spring 896 512 370 4



Nomograph II

to determine screw setting length L_2 , the number of separators N to be used and L_3



WABCO

WABCO
Fahrzeugbremsen
A Division of
WABCO Standard GmbH

Am Lindener Hafen 21
30453 Hannover
Telefon (05 11) 9 22-0
Telefax (05 11) 2 10 23 57