



Kit Content

▪Unpack the system and check all components, the kit should contain the following:-

- | | | | |
|--------------------------|---------------|--------------|---------------------------|
| ▪ Supply cable | 449 172 120 0 | Quantity One | (12m long) |
| ▪ Diagnostic + 24n Cable | 449 684 313 0 | Quantity One | (6m diagnostic / 10m 24N) |
| ▪ Sensor cables | 449 712 030 0 | Quantity Two | (3m long) |
| ▪ EBS Trailer Modulator | 480 102 014 0 | Quantity One | |
| ▪ EBS Label Trailer | 813 000 008 3 | Quantity One | |
| ▪ Publication for Kit | 826 102 180 3 | Quantity One | |
| ▪ Adhesive Label | 899 200 922 4 | Quantity One | |
| ▪ PREV | 971 002 900 0 | Quantity One | |

Once you are satisfied that all the components are correct you can continue with the installation.