

01.04.2010

WABCO Shock Absorbers – additional applications

WABCO already offers more than 200 different applications for motor vehicles, trailers, operator cabs and buses.

To compliment the selection of shock absorbers, we now offer additional variants with clear price advantages for you.

As usual, we provide a list of the new variants with references to all major shock absorber manufacturers as well as an application list of vehicle manufacturers.

All new products are available now

WABCO shock absorbers have undergone extensive testing and meet the high demands of the WABCO specifications. You can count on WABCO quality.

Our new flyer contains more information on our product selection and your advantages when purchasing WABCO shock absorbers.

Open the flyer at <http://www.wabco.info/intl/pdf/820/00/36/8200100363.pdf>



The new selection includes motor vehicle, trailer and cab-shock absorbers

The following is an overview of the new variants with an excerpt from the application data:

Overview of changed shock absorbers April 2010				
Previous WABCO Part number	New WABCO Part number	ZF Sachs	Sabo	Vehicle manufacturer
438 600 008 0	438 600 329 0	124247	890515	Volvo F12
438 600 010 0	438 600 331 0	112869	890812	MAN 16.262 F
438 600 024 0	438 600 333 0	125598	890775	Scania P 114 GB
438 600 028 0	438 600 334 0	106976	890647	DAF 95.310
438 600 029 0	438 600 343 0	131158	890647	DAF 95
438 600 030 0	438 600 335 0	123204	890965	Scania G 112
438 600 037 0	438 600 344 0		890735	Scania G 112
438 600 202 0	438 600 342 0			Renault Premium
438 600 225 0	438 600 338 0	112854	890892	MAN 22.262 FNL
438 600 247 0	438 600 340 0	125649	890607	Volvo F 12
438 600 296 0	438 600 341 0	112128	890922	Volvo F 10
438 601 032 0	438 601 075 0	170191	890476	SAF, Trailor, Weweler
438 601 040 0	438 601 077 0	170192	890446	Meritor, Weweler
438 601 058 0	438 601 078 0		890936	Lohr
438 601 061 0	438 601 079 0		890462	Hendrickson Discos
438 604 009 0	438 604 141 0		895187	Scania 4 Series
438 604 010 0	438 604 161 0		895186	Scania 4 Series
438 604 011 0	438 604 142 0	105874	895187	Scania 4 Series
438 604 015 0	438 604 143 0		895127	Scania 3 Series
438 604 021 0	438 604 145 0		895145	Volvo F 10
438 604 026 0	438 604 147 0		895140	Volvo F 10
438 604 032 0	438 604 148 0		895171	DAF 65, 75, 85
438 604 040 0	438 604 149 0		895271	Volvo FH, FM
438 604 042 0	438 604 162 0		895175	DAF 95 XF
438 604 043 0	438 604 171 0		895161	DAF 95
438 604 044 0	438 604 172 0		895173	DAF 95 XF
438 604 046 0	438 604 150 0	135050	895153	Renault Premium
438 604 052 0	438 604 163 0	124735	895128	Renault Magnum
438 604 058 0	438 604 155 0	290987	895180	Scania 4 Series
438 604 059 0	438 604 156 0	290989	895187	Scania 4 Series
438 604 071 0	438 604 160 0	101378	895120	Mercedes NG, SK

Please talk with your WABCO representative to obtain information on the entire Shock Absorber range.