

Wear indicator retrofit kits for disk brakes, and the New Generation NG22

Having introduced our New Generation NG22 disk brake, we would like to provide you with a complete overview of our wear indicator retrofit kits.



Brake pad wear monitoring (BVA)

- Increased safety
- Lower maintenance cost
- Helps avoid additional damages
- Make's use of the entire service life
- Use of the existing display in the towing vehicle

Requirements:

Trailer's with WABCO EBS or WABCO VCS II with have GIO function's and disk brakes installed by WABCO or Knorr. Appropriate diagnostic software and training is required.

Overview of out retrofit kits and wear indicators:

Axle manufacturer	Disk brake	Axle	Retrofit kit for 1 to 3 axle semitrailers	Retrofit kit for 2 axle draw bar trailer	Brake pad wear indicators (per axle)
SAF	WABCO PAN 19-1 & PAN 19-1 plus	SAF TDB no. 0678 SAF TDB no. 0749	480 102 920 2	480 102 921 2	12 999 755 VT
	WABCO PAN 22-1	SAF test protocol no. 361-094-02 SAF test protocol no. 361-106-02 SAF test protocol no. 361-107-02	480 102 924 2	480 102 925 2	12 999 797
	WABCO NG 22	SAF test protocol no. 361-094-02 SAF test protocol no. 361-106-02 SAF test protocol no. 361-107-02	480 102 927 2	480 102 928 2	640 322 921 2
BPW	Knorr SB6/SN6 & SB7/SN7 & SK7	SAF TDB no. 0590 SAF TDB no. 0591 SAF TDB no. 0605 SAF TDB no. 0606 SAF TDB no. 0764 SAF test protocol no. 361-101-03 SAF test protocol no. 361-102-03 SAF test protocol no. 361-103-03	480 102 922 2	480 102 923 2	12 999 792
	Knorr SB6/SN6 & SB7/SN7 & SK7	BPW TDB no. 0562 BPW TDB no. 0568 BPW TDB no. 0632 BPW TDB no. 0787	480 102 922 2	480 102 923 2	12 999 792

